

Pusher/Cutter Adapter Assembly

Below are instructions to dispense a tote with a 2" BSP fitment using a Western Tooling 2" BSP pusher/cutter adapter with a Western Tooling V50 gate valve.



Items needed:

IC-2036: V50 gate valve

IC-2037: 2" BSP pusher/cutter adapter



Tote is ready for dispense.



Dispense fitment.



Remove crown cutter from fitment.



Flip crown cutter 180° and put back into fitment.



Thread 2" BSP pusher/cutter adapter to V50 gate valve.



Thread V50 gate valve with pusher/cutter adapter to fitment until it stops.



Membrane is now cut, attach necessary adapter.



Tote is ready for dispense.



CDF CORPORATION

CDF Corporation · 77 Industrial Park Road · Plymouth, MA · 02360
800.443.1920 · www.cdf1.com